

# Headboard Assembly

## You will receive:

- Headboard
- Support Struts
- Small Screws x4 +  
Small Allen Key

The headboard can be rotated to install it higher or lower compared to your mattress height. This is so you can have a small gap or a small overlap on your mattress.

**Low setting**  
(mattresses under  
~25cm high)

**High setting**  
(mattresses over  
~25cm high)



## Installing Your Headboard



**Step 1.** Clip in both support struts to the back piece.

**Step 2.** Clip in the headboard to the struts.

For the high setting, install it with the brackets closer to the ground, or rotate it 180 degrees for the low setting.

You may need to push the strut left or right to align it with the bracket.

**Note:** the struts are not designed to reach the ground, and should not touch your skirting boards.

**Step 3.** For a sturdier headboard, install the 4 small screws on each of the 4 strut brackets to lock it all together (highly recommended).